




Connector to Harness Index

Engine Wire Harness ('00-'02 V6 models)

Ref	Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
1	VTEC oil pressure switch	2-GRY	Underside of vehicle, right rear of engine	Body ground via engine wire harness	
2	Oil pressure switch	1-NAT	Underside of vehicle, right rear of engine		
3	VTEC solenoid valve	1-GRY	Underside of vehicle, right rear of engine		
4	T101		Inside under-hood fuse/relay box		
5	CKP sensor	2-GRY	Underside of vehicle, right rear of engine		
6	C108 Junction connector	20-ORN	Below right side of dash		
7	C105 Junction connector	20-ORN	Below right side of dash		
8	G102		Right side of engine		
9	Ignition coil No. 1	3-BLK	Rear center of engine		
10	Ignition coil No. 2	3-BLK	Rear center of engine		
11	PCM connector D	16-GRY	Below center of dash, right side of heater unit		
12	PCM connector B	25-GRY	Below center of dash, right side of heater unit	Left-side engine compartment wire harness (see page 203-14) Left-side engine compartment wire harness (see page 203-14)	
13	Ignition coil No. 3	3-BLK	Rear center of engine		
14	PCM connector C	31-BLU	Below center of dash, right side of heater unit		
15	Primary HO2S	4-GRY	Lower left rear of engine compartment		
16	Fuel injector No. 3	2-BLK	Top of engine		
17	IAT sensor	2-GRY	Left rear of engine		
18	Transmission range switch	10-GRY	Left rear of engine compartment		
19	Countershaft speed sensor	2-BLK	Lower left rear of engine compartment		
20	C106 Junction connector	8-GRY	Lower left rear of engine compartment		
21	C107 Junction connector	14-GRY	Lower left rear of engine compartment		
22	C103	14-GRY	Left rear of engine compartment		
23	C104	10-GRY	Left rear of engine compartment	Body harness via engine wire harness	
24	Radiator fan switch A	2-GRY	Left side of engine		
25	G101		Left side of engine		
26	A/T clutch pressure control solenoid valve A	2-BRN	Left side of engine compartment		
27	A/T clutch pressure control solenoid valve B	2-BLK	Left side of engine compartment		
28	Mainshaft speed sensor	2-BLK	Underside of vehicle, front of transmission		
29	3rd clutch pressure switch	1-BLK	Underside of vehicle, front of transmission		
30	Starter solenoid	1-BLK	Left front of engine compartment		
31	Torque converter clutch solenoid valve/shift control solenoid valve A	3-GRY	Left side of engine compartment		
32	2nd clutch pressure switch	1-BLK	Lower left side of engine, on transaxle		
33	Shift control solenoid valve C	2-BRN	Underside of vehicle, front of transmission	Alternator	
34	IAC valve	3-GRY	Left side of engine		
35	Shift control solenoid valve B	2-BLK	Top of engine		
36	TP sensor	3-GRY	Left side of engine		
37	MAP sensor	3-GRY	Top of engine		
38	EGR valve and EGR valve position sensor	6-GRY	Left side of engine		
39	ECT sensor	2-GRY	Left side of engine		
40	Ignition coil No. 6	3-BLK	Front center of engine		
41	Fuel injector No. 6	2-BLK	Top of engine		
42	Ignition coil No. 5	3-BLK	Front center of engine		
43	Fuel injector No. 5	2-BLK	Top of engine		
44	Alternator	4-GRN	Right front of engine		
45	T102		Right front of engine		
46	Ignition coil No. 4	3-BLK	Front center of engine		
47	Fuel injector No. 4	2-BLK	Top of engine		
48	TDC sensor (1 and 2)	4-GRY	Right side of engine		
49	Fuel injector No. 2	2-BLK	Top of engine		
50	Fuel injector No. 1	2-BLK	Top of engine		
51	Radiator fan switch B	2-GRY	Right side of engine		





Connector to Harness Index

